


Lanner

Network Application Platforms

Hardware platforms for next generation networking infrastructure



FW-7571 V0.5 Preliminary

>>

User's Manual
Publication Date: 2019/03/22

Overview

Icon Descriptions

The icons are used in the manual to serve as an indication of interest topics or important messages. Below is a description of these icons:



NOTE: This check mark indicates that there is a note of interest and is something that you should pay special attention to while using the product.



WARNING: This exclamation point indicates that there is a caution or warning and it is something that could damage your property or product.

Online Resources

The listed websites are links to the on-line product information and technical support.

Resource	Website
Lanner	http://www.lannerinc.com
Product Resources	http://www.lannerinc.com/download-center/
RMA	http://eRMA.lannerinc.com

Copyright and Trademarks

This document is copyrighted, © 2019. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties that may result from such use.

Acknowledgement

Intel, Pentium and Celeron are registered trademarks of Intel Corp.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Compliances

CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Safety Guidelines

Follow these guidelines to ensure general safety:

- Keep the chassis area clear and dust-free during and after installation.
- Do not wear loose clothing or jewelry that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- Disconnect all power by turning off the power and unplugging the power cord before installing or removing a chassis or working near power supplies
- Do not work alone if potentially hazardous conditions exist.
- Never assume that power is disconnected from a circuit; always check the circuit.



LITHIUM BATTERY CAUTION:

Risk of Explosion if Battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions

Operating Safety

Electrical equipment generates heat. Ambient air temperature may not be adequate to cool equipment to acceptable operating temperatures without adequate circulation. Be sure that the room in which you choose to operate your system has adequate air circulation.

Ensure that the chassis cover is secure. The chassis design allows cooling air to circulate effectively. An open chassis permits air leaks, which may interrupt and redirect the flow of cooling air from internal components.

Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. ESD damage occurs when electronic components are improperly handled and can result in complete or intermittent failures. Be sure to follow ESD-prevention procedures when removing and replacing components to avoid these problems.

Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. If no wrist strap is available, ground yourself by touching the metal part of the chassis.

Periodically check the resistance value of the antistatic strap, which should be between 1 and 10 megohms (Mohms).

EMC Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case users will be required to correct the interference at their own expense.

Consignes de sécurité

Suivez ces consignes pour assurer la sécurité générale :

- Laissez la zone du châssis propre et sans poussière pendant et après l'installation.
- Ne portez pas de vêtements amples ou de bijoux qui pourraient être pris dans le châssis. Attachez votre cravate ou écharpe et remontez vos manches.
- Portez des lunettes de sécurité pour protéger vos yeux.
- N'effectuez aucune action qui pourrait créer un danger pour d'autres ou rendre l'équipement dangereux.
-
- Coupez complètement l'alimentation en éteignant l'alimentation et en débranchant le cordon d'alimentation avant d'installer ou de retirer un châssis ou de travailler à proximité de sources d'alimentation.
- Ne travaillez pas seul si des conditions dangereuses sont présentes.
- Ne considérez jamais que l'alimentation est coupée d'un circuit, vérifiez toujours le circuit. Cet appareil génère, utilise et émet une énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions des fournisseurs de composants sans fil, il risque de provoquer des interférences dans les communications radio.

Avertissement concernant la pile au lithium

- Risque d'explosion si la pile est remplacée par une autre d'un mauvais type.
- Jetez les piles usagées conformément aux instructions.
- L'installation doit être effectuée par un électricien formé ou une personne formée à l'électricité connaissant toutes les spécifications d'installation et d'appareil du produit.
- Ne transportez pas l'unité en la tenant par le câble d'alimentation lorsque vous déplacez l'appareil.
- La machine ne peut être utilisée qu'à un lieu fixe comme en laboratoire, salle d'ordinateurs ou salle de classe.



Sécurité de fonctionnement

- L'équipement électrique génère de la chaleur. La température ambiante peut ne pas être adéquate pour refroidir l'équipement à une température de fonctionnement acceptable sans circulation adaptée. Vérifiez que votre site propose une circulation d'air adéquate.
- Vérifiez que le couvercle du châssis est bien fixé. La conception du châssis permet à l'air de refroidissement de bien circuler. Un châssis ouvert laisse l'air s'échapper, ce qui peut interrompre et rediriger le flux d'air frais destiné aux composants internes.
- Les décharges électrostatiques (ESD) peuvent endommager l'équipement et gêner les circuits électriques. Des dégâts d'ESD surviennent lorsque des composants électroniques sont mal manipulés et peuvent causer des pannes totales ou intermittentes. Suivez les procédures de prévention d'ESD lors du retrait et du remplacement de composants.

- Portez un bracelet anti-ESD et veillez à ce qu'il soit bien au contact de la peau. Si aucun bracelet n'est disponible, reliez votre corps à la terre en touchant la partie métallique du châssis.

Vérifiez régulièrement la valeur de résistance du bracelet antistatique, qui doit être comprise entre 1 et 10 mégohms (Mohms).

Consignes de sécurité électrique


- Avant d'allumer l'appareil, reliez le câble de mise à la terre de l'équipement à la terre.
- Une bonne mise à la terre (connexion à la terre) est très importante pour protéger l'équipement contre les effets néfastes du bruit externe et réduire les risques d'électrocution en cas de foudre.
- Pour désinstaller l'équipement, débranchez le câble de mise à la terre après avoir éteint l'appareil.
- Un câble de mise à la terre est requis et la zone reliant les sections du conducteur doit faire plus de 4 mm² ou 10 AWG.

Procédure de mise à la terre pour source d'alimentation CC

Procédure de mise à la terre pour source d'alimentation CC

- Desserrez la vis du terminal de mise à la terre.
- Branchez le câble de mise à la terre à la terre.
- L'appareil de protection pour la source d'alimentation CC doit fournir 30 A de courant.

Cet appareil de protection doit être branché à la source d'alimentation avant l'alimentation CC.



Revision History

version	Changes
0.1	Preliminary
0.2	-Change the DIMM spec to have only one DIMM socket -change port number to be 4 ports on FW-7571B Add the J5 pin header (hardware/software) information
0.3	Added TPM function Added DB9 and USB reserved holes
0.4	Change Installing the Hard Disk Change Installing the CompactFlash Card
0.5	Update BIOS Settings



Table of Contents

Chapter 1: Introduction	1
System Specifications	1
Ordering Information	2
Package Contents	2
Optional Accessories	2
Front Panel Features	3
Rear Panel Features	4
Chapter 2: Hardware Setup	5
Preparing the Hardware Installation.	5
Installing the System Memory	5
Installing the Hard Disk	5
Installing the CompactFlash Card	7
Chapter 3: Motherboard Information	8
Block Diagram	8
Motherboard Layout	9
Jumper Settings	10
Chapter 4: BIOS Settings	15
Accessing the BIOS menu	15
Main	16
Advanced Settings	17
Intel RCSetup	24
Security Settings	27
Boot Configuration.	28
Save & Exit	29
Appendix A: Programming Watchdog Timer	31
Appendix B: Programming Generation 3 LAN Bypass	32
Lanner Generation 3 Bypass.	32
Appendix C: Setting up Console Redirections	33
Appendix D: Programming the LCM	34
Appendix E: Installing Intel QuickAssist Software for Linux	35
Appendix F: Terms and Conditions	36
Warranty Policy	36
RMA Service	36

Chapter 1: Introduction

Thank you for choosing the FW-7571. This system integrates the newest Intel® Atom Processor C2000 series processor, codenamed Rangeley, with the Intel QuickAssist technology to provide a robust and high-performance communication platform. It supports up to 16GB of DDR3 system memory at 1333 or 1600 MHz on dual-channel DIMM banks.

The C2000 series processor comes with an enhanced cryptographic/content processing acceleration via integrated Intel®QuickAssist Integrated Accelerator:

- Bulk Encryption: AES, DES, 3DES, RC4
- Hash: SHA-1, MD5; SHA-2 (SHA-224, SHA-256, SHA-384, SHA-512);
- Authentication: HMAC, AES-XCBC, AES-CCM, and AES-GCM
- Public Key Exchanges: RSA, DH, DSA, ECC

The processor also supports Intel Virtualization Technology.

The FW-7571 is equipped with advanced I/O capabilities ,which incorporates a console port, two Serial-ATA ports as well as a ComplactFlash slot. The front panel also features 6 GbE ports. In addition, the 4 (of all 6) LAN ports on the front panel are equipped with Lanner proprietary Generation 3 bypass.

Regarding the growing security concerns, FW-7571 includess a hardware-based TPM module for system boot-up and data protections.



Please refer to the chart below for a summary of the system’s specifications.

Note: For instructions on quick installation and acquiring the Intel® Atom™ Processor C2000 Product Family for Communications Infrastructure Software for Linux* Software package, refer to the attached PDF file.

System Specifications

Form Factor		1U Rackmount
Platform	Processor Options	2-core Intel® Atom Processor C2358 (Codenamed "Rangeley")
	BIOS	
		AMI BIOS 16Mbit
		TPM secure-boot
System Memory	Technology	Dual-channel DDR3 1333/1600 MHz (ECC or non-ECC)
	Max. Capacity	16 GB
	Socket	1 x 240-pin DIMM
OS Support		Linux Kernel 2.6 or above
Storage	HDD Bays	2 x 2.5" HDD/SSD kit or 3.5" HDD (optional)
	CompactFlash	1 x Type II CompactFlash
Networking	Ethernet Ports	6 x GbE RJ45 onboard (FW-7571A) 4 x GbE RJ45 onboard (FW-7571B)
	Bypass	2 pairs Generation 3 (on model FW-7571A only)
	Controllers	2 x Intel i210AT, 1 x Marvell 88E1543
	Ethernet Modules	N/A
	Management Port	N/A
I/O Interface	Reset Button	1 x reset button Software reset by default
	Console	1 x RJ45
	USB	2 x USB 2.0
	IPMI via OPMA slot	N/A
	Display	N/A
Expansion	PCIe	N/A
	PCI	N/A
	DB9	Reserved
	USB	Reserved
Cooling	Processor	CPU heatsink
	System	1x cooling Fan with smart fan control
Environmental Parameters	Temperature, ambient operating / storage	0 ~ 40° C / -20~70° C
	Humidity (RH), ambient operating / ambient non-operating	5~90%, non-condensing / 5~95%, non-condensing



Miscellaneous	LCD Module	N/A
	Watchdog	Yes
	Internal RTC with Li Battery	Yes
Physical Dimensions	Dimensions (WxHxD)	431 x 44 x 305 mm
	Weight	4 kg
Power	Type/Watts	150W ATX Power Supply Unit
	Input	100~240V@50~60Hz
Approvals and Compliance	CE Class A, FCC Class A, RoHS	

Ordering Information

FW-7571A	Intel® Atom™ processor C2358, 6 GbE LAN ports with Gen.3 Bypass, 100 or 150W ATX PSU, and TPM
FW-7571B	Intel® Atom™ processor C2358, 4 GbE LAN ports without Bypass, 150W ATX PSU, and TPM

Package Contents

Your package contains the following items:

- FW-7571 Network Security Platform
- Power cable
- 1 console cable
- Serial-ATA hard drive cable
- 1 threaded screw set
- 1 ear bracket set
- Drivers and user's manual CD.


Optional Accessories

The system has a variety of optional accessories, visit the following website for more information.

<http://www.lannerinc.com/products/x86-network-appliances/rackmount/fw-7571>



Front Panel Features



F1 Power/Status/HDD LED

Power: If the LED is on it indicates that the system is powered on. If it is off, it indicates that the system is powered off.

Status: This LED is programmable. You could program it to display the operating status with the following behavior:

If the LED is green, it indicates that the system's operational state is normal. If it is red, it indicates that the system is malfunctioning.

HDD: If the LED blinks, it indicates data access activities; otherwise, it remains off.

F2 Reset Switch

The reset switch can be used to reboot the system without turning off the power. The reset switch can act as a software or a hardware reset with jumper settings. The default is software reset. (Refer to **Chapter 3 Motherboard Information.**)

F3 Console Port

By using suitable rollover cable or RJ-45 to DB-9 console cable, you can connect to a computer terminal for diagnostic or configuration purpose. Terminal Configuration Parameters: 115200 baud, 8 data bits, no parity, 1 stop bit, no flow control.

F4 Two USB 2.0 Ports

It connects to any USB devices, for example, a flash drive.

F5 Ethernet Ports (LAN1-LAN2: bypass pair; LAN3-LAN4: bypass pair*)

LINK/ACT (Yellow)

- On/Flashing: The port is linking and active in data transmission.
- Off: The port is not linking.

SPEED (Green/Amber)

- Amber: The connection speed is 1000Mbps.
- Green: The connection speed is 100Mbps
- Off: .The connection speed is 10Mbps.

4 (of all 6) on-board Ethernet ports with 2 pairs of LAN bypass. These 4 GbE ports are provided by Marvell 88E1543 and the other two are provided by Intel i210AT. LAN5 is capable of Preboot eXecution Environment (PXE) (This feature needs to be enabled or disabled in the BIOS; the default is disabled). Two pairs (LAN1-LAN2, LAN3-LAN4) can be configured as LAN Bypass by using Lanner Gen3 Bypass technology when failure events occur. This feature can be enabled dynamically with a watchdog timer. Refer to your User's Manual CD for a sample implementation of this feature.

Note:

1. The LAN bypass functionality is only available on model FW-7571A
2. Model FW-7571B only has 4 Ethernet ports.

Rear Panel Features



R1 Reserved for PCIe Expansion Slot

R2 CPU Fan

This fan has smart fan feature which can be turned on automatically when the temperature exceeds the set threshold.

R3 Power-on Switch

It is a switch to turn on or off the power.

R4 AC Power Socket

The system equips an ATX 150W Power Supply.

Chapter 2: Hardware Setup

Preparing the Hardware Installation

To access some components and perform certain service procedures, you must perform the following procedures first.



WARNING: To reduce the risk of personal injury, electric shock, or damage to the equipment, remove the power cord to remove power from the server. The front panel Power On/Standby button does not completely shut off system power. Portions of the power supply and some internal circuitry remain active until AC power is removed.


1. Unpower the FW-7571 and remove the power cord.
2. Unscrew 2 screws on each side and the rear of the top cover of the FW-7571 System.
3. Slide the cover backwards to open it.



Installing the System Memory

The motherboard supports DDR3 memory that features data transfer rates of 1333, 1600 MHz to meet the higher bandwidth requirements of the latest operating system and Internet applications. To install the memory:

1. Open the DIMM slot latches.
2. Install the DIMM.




Note:

1. The system can support up to 16 GB in maximum.



Installing the Hard Disk

The system can accommodate two 2.5" Serial-ATA disks. Follow these steps to install a hard disk into the FW-7571:








Note: Please note the orientation of the HDD tray placement when you take out the tray. It is recommended that the HDD is installed in this orientation on the system.

Note: Note that the original package includes only one SATA cable, You need to order another cable for additional SATA HDD installation.

1. Locate the disk bay area in the chassis.
2. Loosen the three screws that secure the empty HDD tray.
3. Insert the four rubber washers into the four notches of the tray.
4. Flip the tray over, and secure the disk on the tray with the four provided disk screws. Make sure the SATA contacts face outward as shown in the picture.
5. Insert one end of the SATA data cable to the SATA contacts on the disk. Do the same to the SATA power cable.
6. Secure the tray on the motherboard with three provided screws.
7. Insert the other end of the SATA data cable to a SATA port on the motherboard.
8. Insert the other end of the SATA power cable to a SATA Power port.

Arrange the cables and route them neatly to avoid them from getting tangled.



Installing the CompactFlash Card

FW-7571 provides one CompactFlash slot. Follow the procedures bellow for installing a CompactFlash card.

1. Align CompactFlash card and the card slot with the arrow pointing toward the connector. The card fits only the correct way into the slot; do not force the card into the slot.
2. Push the card to insert into the connector.



This side is left blank intentionally.




Chapter 3: Motherboard Information

Block Diagram


The block diagram depicts the relationships among the interfaces or modules on the motherboard. Please refer to the following figure for your motherboard's layout design.

MB-7571



Motherboard Layout

The motherboard layout shows the connectors and jumpers on the board. Refer to the following picture as a reference of the pin assignments and the internal connectors.




Chapter 3

Motherboard Information

Jumper Settings


Fan Connectors(FAN2): The 5-pin connector is for connecting the CPU fan. It comes with the smart fan feature by which the fan could be monitored and turned on when the temperature exceed the set threshold.

Pin No.	1	2	3	4	5
Function	PWM	NC	RPM Sense	+12V	Ground




Note: FAN2 (CPU) fan can be set to be in either manual mode or smart fan mode in the BIOS menu.

ATX Power Connector (ATX11): This 24-pin connector are for connecting ATX power supply plugs. Find the proper orientation when inserting the plugs, for the supply plugs are designed to fit these connectors in only one orientation.




Pin No.	Function	Pin NO.	Function
1	+3.3V	2	+3.3V
3	Ground	4	+5V
5	Ground	6	+5V
7	Ground	8	Power Good
9	Standby 5V	10	+12V
11	+12V	12	+3.3V
13	+3.3V	14	-12V
15	Ground	16	PSON-
17	Ground	18	Ground
19	Ground	20	NC
21	+5V	22	+5V
23	+5V	24	GND

USB Connector(USB2): It is for connecting the USB module cable. It complies with USB2.0 and support up to 480 Mbps connection speed.



Pin No.	Function	Pin No.	Function
1	USB_VCC	2	USB_VCC
3	USB D2-	4	USB D3-
5	USB D2+	6	USB D3+
7	Ground	8	Ground
9	Ground	10	Ground

Dual USB 2.0 Ports (USB1): This provides two USB 2.0 ports in the front panel.



Pin No.	Function
1	USB_VCC
2	USB D0-
3	USB D0+
4	GND
5	USB_VCC
6	USB D1-
7	USB D1+
8	GND

Console Port (COM1)

Pin No.	Function	Pin No.	Function
1	RTS-	6	SIN
2	DTR-	7	DSR-
3	SOUT	8	CTS-
4	GND		
5	GND		




Chapter 3

Motherboard Information

Serial Interface Connectors(COMB1): It is for connecting the RS-232 serial port (COM2) interface cable.

COMB1



Pin No.	Function	Pin No.	Function
1	Data Carrier Detect (DCDB#)	2	Data Set Ready (DSRB#)
3	Receive Data (RXDB)	4	Request To Send (RTSB#)
5	Transmit Data (TXDB)	6	Clear To Send (CTSB #)
7	Data Terminal Ready (DTRB#)	8	Ring Indicator (RIB#)
9	GND	10	Key

LAN 1~4: LAN Connector(RJ-45, provided by Intel Marvell 88E1543)


LAN 5~6 Connector (RJ-45, provided by Intel Ethernet i210AT)

Clear CMOS jumper (JBAT1): It is for clearing the CMOS memory and system setup parameters by erasing the data stored such as the system passwords in the CMOS RAM.



Pin No.	Function
1-2 (Default)	Normal
2-3	Clear CMOS

CompactFlash Connector (CF2): It is for connecting a Compact Flash card to be served as your system's storage. The connector is a CF Type II slot which could fit both CF Type I or CF Type II cards.



Pin No.	Function	Pin No.	Function
1	GND	26	CD1-
2	DATA3	27	DATA11
3	DATA4	28	DATA12
4	DATA5	29	DATA13
5	DATA6	30	DATA14
6	DATA7	31	
7	CE1#	32	DATA15
8	A10	33	CE2#
9	OE#	34	VS1#
10	A9	35	IOR#
11	A8	36	IOW#
12	A7	37	WE#
13	CFVCC3	38	READY#
14	A6	39	CFVCC3
15	A5	40	CSEL
16	A4	41	VS2#
17	A3	42	RESET
18	A2	43	WAIT#
19	A1	44	INPACK#
20	A0	45	REG#
21	DATA0	46	DASP#
22	DATA1	47	DIAG#
23	DATA2	48	DATA8
24	WP	49	DATA9
25	CD2-	50	DATA10
			GND



DIMM Socket (DIMM1): The 240-pin DDR3 DIMM is for connecting the DDR3 1333/1600 memory. The system can support up to 16 GB in maximum.

SATA Connector (SATA6G_1, SATA6G_2): It is for connecting a SATA harddisk to be served as your system's storage. The system can accommodate 2 disk2 (2.5) with 3.0 standard. The controller contains two modes of operation—a legacy mode using I/O space, and an AHCI mode using memory space. Software that uses legacy mode will not have AHCI capabilities.

The AHCI (Advanced Host Controller Interface) is a programming interface which defines transactions between the SATA controller and software and enables advanced performance and usability with SATA. Platforms supporting AHCI may take advantage of performance features such as no master/slave designation for SATA devices—each device is treated as a master—and hardware assisted native command queuing. AHCI also provides usability enhancements such as Hot-Plug.

Note:



1. You will need to configure your SATA as AHCI mode in the BIOS in order to use the advanced features of SATA. To do this, access the BIOS menu under Advanced-> SATA Configuration->SATA mode.
2. Also, the hotplug enable/disable option is under the same SATA Configuration menu. Enable the hotplug function explicitly in this menu if you need it.

7		Pin No.	Function
6		1	GND
5		2	TX_P
4		3	TX_N
3		4	GND
2		5	RX_N
1		6	RX_P
	7	GND	

4-Pin SATA Power Connector (PS4P1, PS4P2)

	Pin No.	Function
	1	+12V
	2	GND
	3	Ground
	4	5V

AT Mode Power Button Connector (CONN1) It is for connecting the power switch in AT mode

	Pin No.	Function
	1	PS_ON#
	2	GND

Reset Switch (SW2) and Reset Button Connector (CONN2)

Hardware or Software Reset Jumper (J5): The jumper can be adjusted to be in either hardware or software reset mode when the reset switch is pressed. The hardware reset will reboot the system without turning off the power. The software reset can be programmed to reset software to its default setting.

	Pin No.	Function
	1-2	Hardware Reset
	2-3	Software Reset (default)



Chapter 3

Motherboard Information

Digital GPIO (GPIO1) Connector



Pin No.	Function	Pin No.	Function
1	GPO4	2	GPIO
3	GPO5	4	GPI1
5	GPO6	6	GPI2
7	GPO7	8	GPI3
9	GND	10	GND

SPI-ROM Update Connector (SPI-ROM1): It is for updating the SPI Flash soldered on board for service and repair purposes.



Pin No.	Function	Pin No.	Function
1	NC	2	NC
3	SPI_CS0	4	V_3P3_SPI_R
5	SPI_MISO_DUAL	6	SPI_HOLD0_L
7	NC	8	SPI_CLK_DUAL
9	GND	10	SPI_MOSI_DUAL

LPC I/O bus (It can also be called Port 80) (LPC1): It is a proprietary connector for connecting a checkpoint device to output checkpoints throughout booting and Power-On Self Test (POST) to indicate the task the system is currently executing.



Pin No.	Function	Pin No.	Function
1	CLK_33M_P80	2	LPC_AD1
3	PLTRST_P80	4	LPC_ADO
5	LPC_FRAME_N	6	P3V3
7	LPC_AD3	8	GND
9	LPC_AD2	10	GND

PCIe Expansion Connector (PCIEC1): PCIe expansion connector (two PCIe x 4) for front Ethernet module or other type of expansion through the back panel.

PIN NO.	FUNCTION	PIN NO.	FUNCTION
B1	+12V	A1	PRSNT1#
B2	+12V	A2	+12V
B3	+12V	A3	+12V
B4	GND	A4	GND
B5	SMCLK	A5	NC
B6	SMDAT	A6	NC
B7	GND	A7	NC
B8	+3.3V	A8	NC
B9	NC	A9	+3.3V
B10	3.3VAUX	A10	+3.3V
B11	WAKE#	A11	PLTRST#
B12	RSVD_A	A12	GND
B13	GND	A13	REFCLK_+
B14	HSOP0_H	A14	REFCLK_-
B15	HSO00_L	A15	GND
B16	GND	A16	HSI00_H
B17	PRSNT2#	A17	HSI00_L
B18	GND	A18	GND
B19	HSOP1_H	A19	RSVD_B
B20	HSO01_L	A20	GND
B21	GND	A21	HSI01_H
B22	GND	A22	HSI01_L
B23	HSOP2_H	A23	GND
B24	HSO02_L	A24	GND
B25	GND	A25	HSI02_H
B26	GND	A26	HSI02_L
B27	HSOP3_H	A27	GND
B28	HSO03_L	A28	GND
B29	GND	A29	HSI03_H
B30	RSVD_C	A30	HSI03_L
B31	PRSNT2#	A31	GND
B32	GND	A32	RSVD_D
B33	HSOP4_H	A33	RSVD_E
B34	HSO04_L	A34	GND
B35	GND	A35	HSI04_H
B36	GND	A36	HSI04_L
B37	HSOP5_H	A37	GND
B38	HSO05_L	A38	GND
B39	GND	A39	HSI05_H
B40	GND	A40	HSI05_L
B41	HSOP6_H	A41	GND
B42	HSO06_L	A42	GND
B43	GND	A43	HSI06_H
B44	GND	A44	HSI06_L
B45	HSOP7_H	A45	GND
B46	HSO07_L	A46	GND
B47	GND	A47	HSI07_H
B48	PRSNT2#	A48	HSI07_L
B49	GND	A49	GND



Case open (OPEN1): Case opening detection pin header



Pin No.	Description
1	GND
2	SIO_CASEOPEN#

Chapter 4: BIOS Settings

Accessing the BIOS menu

When you are installing a motherboard or when the system prompts “Run Setup” during start-up, you will use the BIOS Setup program to configure the system, . This section explains how to configure your system using this program.

Even if you are not prompted to enter the BIOS Setup program when you are installing a motherboard, you can still change the configuration of your computer later on with this program. For example, you may want to enable the security password feature or change the power management settings. This requires you to reconfigure your system by using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM .

When you start up the computer, the system provides you with the opportunity to run this program. Press <Delete> during the Power-On-Self-Test (POST) to enter the Setup utility (There are a few cases that other keys may be used, such as <F1>, <F2>, and so forth.); otherwise, POST continues with its test routines.

If you wish to enter Setup after POST, restart the system by pressing <Ctrl+Alt+Delete>, or by pressing the reset button on the system chassis. You can also restart by turning the system off and then back on. Do this last option only if the first two failed.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.




Note: This manual describes the standard look of the setup screen. There may be some instances in which the motherboard features can vary from one to another due to customization. This means that some of the options described in this manual may not match that of your motherboard’s AMIBIOS.

Navigating the BIOS menu

The BIOS setup utility uses a key-based navigation system called hot keys. Most of the BIOS setup utility hot keys can be used at any time during the setup navigation process.

These keys include <F1>, <F10>, <Enter>, <ESC>, <Arrow> keys, and so on.



Control Keys

→←	Select Screen
↑↓	Select Item
<Enter>	Select
+/-	Change Option
F1	General help
F2	Previous Values
F3	Optimized Defaults
F4	Save & Exit
<Esc>	Exit




The Main Menu

The main BIOS setup menu is the first screen that you can navigate. Each main BIOS setup menu option is described in this chapter.

The Main BIOS setup menu screen has two main frames. The left frame displays all the options that can be configured. “Grayed-out” options are configured parameters and cannot be modified. On the other hand, Options in blue can be modified.

The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it.




Feature	Description
BIOS Information	BIOS Vendor: American Megatrends Core Version: AMI Kernel version, CRB code base, X64 Compliance: UEFI version, PI version Project Version: BIOS release version Build Date and Time: MM/DD/YYYY Access Level: Administrator / User
Total Memory	Total memory size
System Language	English
System Date	To set the Date, use <Tab> to switch between Date elements. Default Range of Year: 2005-2099 Default Range of Month: 1-12 Days: dependent on Month.
System Time	To set the Date, use <Tab> to switch between Date elements.



Advanced Settings

Select the Advanced tab from the setup screen to enter the Advanced BIOS Setup screen. You can select any of the items in the left frame of the screen, such as SuperIO Configuration, to go to the sub menu for that item. You can display an Advanced BIOS

Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screen is shown at the right. The sub menus are described on the following pages.



Feature	Options	Description
PXE Function	Enabled Disabled	PXE Function

PXE Function

The Preboot eXecution Environment (PXE) allows you to boot computers using a network interface independently of data storage devices (like hard disks) or installed operating systems. Enable or disable this function with this option here. For LAN port that can be configured to PXE function, refer to **Chapter 1 Introduction**.




Chapter 4

Bios Settings


NCT6776 Super IO configuration

Serial Port 1/2 Configuration




Serial Port 1 Configuration

Feature	Options	Description
Serial Port	Enabled Disabled	Enable or Disable Serial Port (COM)
Device Settings	NA	IO=3F8h; IRQ = 4




Serial Port 2 Configuration

Feature	Options	Description
Serial Port	Enabled Disabled	Enable or Disable Serial Port (COM)
Device Settings	NA	IO=2F8h; IRQ = 3



Parallel port Configuration

Feature	Options	Description
Serial Port	Enabled Disabled	Enable or Disable Parallel Port (LPT/LPTE)
Device Settings	NA	IO=378h; IRQ = 5



NCT6776 HW Monitor

This menu shows the hardware monitor configuration settings. Select an item then press <Enter> to display the configuration options.

SYS/CPU Temperature

The onboard hardware monitor automatically detects and displays the CPU and motherboard temperatures.

FAN2 Speed (CPU FAN)

The onboard hardware monitor automatically detects and displays the CPU fan speeds in rotations per minute (RPM). If the fan is not connected to the motherboard, it displays N/A.

CPU Voltage, 3.3V voltage, 5V voltage, VBAT, etc

The onboard hardware monitor automatically detects the voltage output through the onboard voltage regulators.

Smart Fan Configuration

It allows you to configure the smart fan feature. You can manually turn on the CPU fan or set the target CPU temperature at which the CPU fan will start running if the fan is not yet turned on. And the CPU fan can also be turned off automatically if the temperature for the CPU is at or below the specified value.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
  Advanced
-----
Pc Health Status                                     |Enable or Disable Smart
Smart Fan Function [Enabled]                         |Fan
> Smart Fan Configuration                            |
SYS temperature : +32 C                             |
CPU temperature : +55 C                             |
FAN2 Speed(CPUFAN) : 7894 RPM                       |
V CORE          : +0.960 V                           |
V DDR           : +1.504 V                           |
V IO            : +1.000 V                           |
V 5V            : +5.040 V                           |>: Select Screen
V 3.3V          : +3.296 V                           |^v: Select Item
V SB3V         : +3.344 V                           |Enter: Select
V BAT          : +3.248 V                           |+/-: Change Opt.
                                                    |F1: General Help
                                                    |F2: Previous Values
                                                    |F3: Optimized Defaults
                                                    |F4: Save & Exit
                                                    |ESC: Exit
-----
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

Feature	Options	Description
Smart Fan Function	Enabled Disabled	Enable or Disable Smart Fan

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
  Advanced
-----
Smart Fan Configuration                               |Smart Fan Mode select
CPU Smart Fan Mode [SMART FAN IV Mode]              |
                                                    |>: Select Screen
                                                    |^v: Select Item
                                                    |Enter: Select
                                                    |+/-: Change Opt.
                                                    |F1: General Help
                                                    |F2: Previous Values
                                                    |F3: Optimized Defaults
                                                    |F4: Save & Exit
                                                    |ESC: Exit
-----
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

Feature	Options	Description
CPU Smart Fan Mode	Full Speed SMART FAN IV Mode	Smart Fan Mode select




Serial Port Console Redirection


Use this menu to set the settings for BIOS remote access feature.

COM0 Console Redirection Settings

Feature	Options	Description
Terminal Type	VT100 VT100+ VT-UTF8 ANSI	VT100: ASCII char set VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes ANSI: Extended ASCII char set
Bits per second	9600 19200 38400 57600 115200	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
Data Bits	7 8	Data Bits
Parity	None Even Odd Mark Space	A parity bit can be sent with the data bits to detect some transmission errors.
Stop Bits	1 2	Indicates the end of a serial data packet.
Flow Control	None Hardware RTS/CTS	Flow Control can prevent data loss from buffer overflow.
VT-UTF8 Combo Key Support	Disabled Enabled	Enables VT-UTF8 Combination Key Support for ANSI/VT100 terminals
Recorder Mode	Disabled Enabled	With this mode enabled, only text will be sent. This is to capture Terminal data.
Resolution 100x31	Disabled Enabled	Enables or disables extended terminal resolution
Legacy OS Redirection Resolution	80x24 80x25	On Legacy OS, the Number of Rows and Columns supported redirection
Putty KeyPad	VT100 LINUX XTERM86 SCO ESCN VT400	Selects FunctionKey and Keypad on Putty.
Redirection After BIOS POST	Always Enable BootLoader	The Settings specify if BootLoader is selected than Legacy console redirection is disabled before booting to Legacy OS. Default value is Always Enable which means Legacy console Redirection is enabled for Legacy OS.




Feature	Options	Description
COM0 Console Redirection	Enabled Disabled	Enables or disables Console Redirection




Network Stack Configuration

Feature	Options	Description
Network Stack	Disabled Enabled	Enables or disables UEFI Network Stack
Ipv4 PXE Support	Disabled Enabled	Enables Ipv4 PXE Boot Support. If IPV4 is disabled, PXE boot option will not be created.
Ipv6 PXE Support	Disabled Enabled	Enables Ipv6 PXE Boot Support. If IPV6 is disabled, PXE boot option will not be created.
PXE boot wait time	0	Wait time to press <ESC> key to abort the PXE boot




CSM Configuration

Feature	Options	Description
CSM Support	Disabled Enabled	Enables or disables CSM Support
GateA20 Active	Upon Request Always	UPON REQUEST - GA20 can be disabled using BIOS services. ALWAYS - do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.
Option ROM Messages	Force BIOS Keep Current	Set display mode for Option ROM
INT19 Trap Response	Immediate Postponed	BIOS reaction on INT19 trapping by Option ROM: IMMEDIATE - execute the trap right away; POSTPONED - execute the trap during legacy boot.
Boot option filter	UEFI and Legacy Legacy only UEFI only	This option controls Legacy/UEFI ROMs priority
Network	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy PXE OpROM
Storage	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy Storage OpROM
Video	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy Video OpROM
Other PCI device	Do Not Launch UEFI Legacy	Determines OpROM execution policy for devices other than Network, Storage, or Video



USB Configuration Setting

You can use this screen to select options for the USB Configuration. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option. The settings are described on the following pages.



Feature	Options	Description
Legacy USB Support	Enabled Disabled Auto	Enables Legacy USB support. Auto option disables legacy support if no USB devices are connected; Disabled option will keep USB devices available only for EFI applications.
EHCI Hand-off	Enabled Disabled	This is a workaround for Oses without EHCI hand-off support. The EHCI ownership change should be claimed by EHCI driver.
USB Mass Storage Driver Support	Enabled Disabled	Enables or disables USB Mass Storage Driver Support.
USB transfer time-out	1 sec 5 sec 10 sec 20 sec	The time-out value for Control, Bulk, and Interrupt transfers
Device reset time-out	1 sec 5 sec 10 sec 20 sec	USB mass storage device Start Unit command time-out
Device power-up delay	Auto Manual	Maximum time the device will take before it properly reports itself to the Host Controller. Auto uses default value: for a Root port, it is 100 ms, for a Hub port the delay is taken from Hub descriptor.



Intel RCSetup

You can use this screen to view the capabilities and of your CPU. You can also use this menu to enable/disable certain functions of your CPU. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option. A description of the selected item appears on the right side of the screen. The settings are described below.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Security Boot Save & Exit

-----
| MRC Version          1.0.0.39          |Displays and provides
| Microcode Revision   0000012A         |option to change the
|> Processor Configuration              |Processor Settings
|> North Bridge Chipset Configuration
|> South Bridge Chipset Configuration
-----
|<: Select Screen
|^v: Select Item
|Enter: Select
|+/-: Change Opt.
|F1: General Help
|F2: Previous Values
|F3: Optimized Defaults
|F4: Save & Exit
|ESC: Exit
-----
Setup Warning:
Setting items on this Screen to incorrect
may cause system to malfunction!
-----
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

Feature	Options	Description
Processor Configuration	None	Displays and provides option to change the Processor Settings
North Bridge Chipset Configuration	None	North Bridge Chipset Configuration
South Bridge Chipset Configuration	None	South Bridge Chipset Configuration



Processor Configuration

Feature	Options	Description
EIST (GV3)	Disabled Enabled Auto	Enable/Disable EIST. GV3 and TM1 must be enabled for TM2 to be available. GV3 must be enabled for Turbo. Auto - Enable for B0 CPU stepping, all others disabled, change setting to override.
TM1	Disabled Enabled	Enable/Disable TM1. TM1 and GV3 must be enabled in order to support TM2
CPU C State	Disabled Enabled Auto	Enables the Enhanced C _{xx} state of the CPU, takes effect after reboot. Auto - Enable for B0 CPU stepping, all others disabled, change setting to override.
Execute Disable Bit	Disabled Enabled	When disabled, forces the XD feature flag to always return 0.
Turbo	Disabled Enabled	Enable or Disable CPU Turbo capability. This option only applies to ES2 and above.
Active Processor Cores	ALL 4 2	Number of cores to enable in SoC package.

North Bridge Chipset Configuration

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
IntelRCSetup

-----
Processor Configuration
-----
Processor ID          000406D8
Processor Frequency   2.407GHz
L1 Cache RAM         448KB
L2 Cache RAM         4096KB
Processor Version     Intel(R) Atom(TM) CPU C
                    2758 @ 2.41GHz

EIST (GV3)           [Disable]
TM1                   [Enable]
CPU C State           [Disable]
Execute Disable Bit   [Enable]
Turbo                 [Disable]
Active Processor Core [All]

|-----|
| Enable/Disable EIST. |
| GV3 and TM1 must be |
| enabled for TM2 to be |
| available. GV3 must be |
| enabled for Turbo. Auto |
| - Enable for B0 CPU |
| stepping, all others |
| disabled, change |
| setting to override. |
|-----|
|<: Select Screen
|^v: Select Item
|Enter: Select
|+/-: Change Opt.
|F1: General Help
|F2: Previous Values
|F3: Optimized Defaults
|F4: Save & Exit
|ESC: Exit
|-----|

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
IntelRCSetup

-----
North Bridge Chipset Configuration
-----

Memory Information
Total Memory          2048 MB
Memory Frequency     DDR3 - 1333 MHz

|-----|
|><: Select Screen
|^v: Select Item
|Enter: Select
|+/-: Change Opt.
|F1: General Help
|F2: Previous Values
|F3: Optimized Defaults
|F4: Save & Exit
|ESC: Exit
|-----|

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

South Bridge Chipset Configuration

Feature	Options	Description
SMBUS Controller	Enabled Disabled	SMBUS Controller options
Restore On Power Loss	Auto Power On Power Off	Restore On AC Power Loss Options

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
IntelRCSetup

-----
South Bridge Chipset Configuration
-----

SMBUS Controller     [Enabled]
Restore On Power Loss [Auto]
> SATA Configuration

|-----|
| SMBUS Controller options |
|-----|
|><: Select Screen
|^v: Select Item
|Enter: Select
|+/-: Change Opt.
|F1: General Help
|F2: Previous Values
|F3: Optimized Defaults
|F4: Save & Exit
|ESC: Exit
|-----|

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```



SATA Configuration

While entering Setup, the BIOS automatically detects the presence of SATA devices. The SATA Port items show “Not Installed” if no SATA device is installed to the corresponding SATA port.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
  IntelRCSetup
-----
SATA 2 controller                ^| Enables/Disables sata
                                *| controller if supported
                                *| by current cpu SKU.
Sata controller                  [Enabled]
Sata mode                        [AHCI]
SATA Port 0                      InnoDisk Corp. - 32.0 GB
Sata port 0                      [Enabled]
Spin up                          [Disabled]
External device                  [Disabled]
Hot plug                         [Disabled]
Mechanical Switch                [Disabled]
SATA Port 1                      [Not Installed]
Sata port 1                      [Enabled]
Spin up                          [Disabled]
External device                  [Disabled]
-----
+|>: Select Screen
+|^v: Select Item
+|Enter: Select
+|+/-: Change Opt.
+|F1: General Help
+|F2: Previous Values
+|F3: Optimized Defaults
+|F4: Save & Exit
v|ESC: Exit
-----
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

Feature	Options	Description
SATA controller	Enabled Disabled	Enables/Disables SATA controller if supported by current CPU SKU.
SATA mode	IDE AHCI	Sata mode
SATA port 0/1/2/3/4/5	Enabled Disabled	Enables/Disables SATA device if supported by current CPU SKU.
Spin up	Enabled Disabled	Spin up
External device	Enabled Disabled	External SATA device
Hot plug	Enabled Disabled	Hot plug
Mechanical Switch	Enabled Disabled	Mechanical Switch



Security Settings

Select Security Setup from the Setup main BIOS setup menu. All Security Setup options, such as password protection and virus protection, are described in this section. To access the sub menu for the following items, select the item and press <Enter>

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Security Boot Save & Exit


-----
Password Description                                |Set Administrator
                                                    |Password
-----
If ONLY the Administrator's password is set,      |
then this only limits access to Setup and is     |
only asked for when entering Setup.              |
If ONLY the User's password is set, then this    |
is a power on password and must be entered to   |
boot or enter Setup. In Setup the User will     |
have Administrator rights.                       |
The password length must be                      |
in the following range:                          |
Minimum length          3                        |
Maximum length          20                       |
-----
Administrator Password                             |
User Password █                               |
                                                    |
                                                    |>: Select Screen
                                                    |^v: Select Item
                                                    |Enter: Select
                                                    |+/-: Change Opt.
                                                    |F1: General Help
                                                    |F2: Previous Values
                                                    |F3: Optimized Defaults
                                                    |F4: Save & Exit
                                                    |ESC: Exit
-----
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

Feature	Description
Administrator Password	If ONLY the Administrator's password is set, it only limits access to Setup and is only asked for when entering Setup.
User Password	If ONLY the User's password is set, it serves as a power-on password and must be entered to boot or enter Setup. In Setup, the User will have Administrator rights.



Boot Configuration

In this screen, you will be able to configure the boot procedures and the related elements.




Feature	Options	Description
Setup Prompt Timeout	1	The number of seconds to wait for setup activation key. 65535 means indefinite waiting.
Bootup NumLock State	On Off	Select the keyboard NumLock state
Quiet Boot	Disabled Enabled	Enables or disables Quiet Boot option.
HDD BootSector Write	Normal Write Protect	Enables or disables writes to Hard Disk Sector 0

Choose boot priority from boot option group.




Save and Exit

Select the Exit tab from the setup screen to enter the Exit BIOS Setup screen. You can display an Exit BIOS Setup option by highlighting it using the <Arrow> keys. The following table lists the options in this menu.




■ Save Changes and Reset

When Users have completed the system configuration changes, select this option to save the changes and exit from BIOS Setup in order for the new system configuration parameters to take effect. The following window will appear after selecting the "Save Changes and Exit" option is selected. Select "Yes" to Save Changes and Exit Setup.




■ Discard Changes and Exit

Select this option to quit Setup without saving any modifications to the system configuration. The following window will appear after the "Discard Changes and Exit" option is selected. Select "Yes" to Discard changes and Exit Setup.



■ Restore Defaults

Restore default values for all setup options. Select "Yes" to load Optimized defaults.





Appendix A: Programming Watchdog Timer

A watchdog timer is a piece of hardware that can be used to automatically detect system anomalies and reset the processor in case there are any problems. Generally speaking, a watchdog timer is based on a counter that counts down from an initial value to zero. The software selects the counter's initial value and periodically restarts it. Should the counter reach zero before the software restarts it, the software is presumed to be malfunctioning and the processor's reset signal is asserted. Thus, the processor will be restarted as if a human operator had cycled the power.

For sample watchdog code, see *watchdog* folder on the *Driver and Manual CD*



To execute the sample code: enter the number of seconds to start count down before the system can be reset. Press start to start the counter and stop to stop the counter..

`Dwd_tst --swt xxx` (Set Watchdog Timer 1-255 seconds)

`wd_tst[*] --start` (Start Watchdog Timer)

`wd_tst --stop` (Stop Watchdog Timer)

For sample watchdog code, see *watchdog* folder on the *Driver and Manual CD*



Appendix B: Programming Generation 3 LAN Bypass

Lanner Generation 3 Bypass

The bypass function is used to link two independent Ethernet ports when the system crashes or powers off. This means if your system is equipped with a LAN Bypass function, a condition in your system will not interrupt your network traffic. Different from the previous two generations (Gen1 and Gen2), the Lanner Bypass Gen 3 employs a programming method to control the bypass function by software. There are typically two communication status for the bypass function, one is "Normal" and another is "Bypass" status. Furthermore, the Lanner Bypass software is capable to control the bypass status in the following 3 states:

1. When the system powers off, it can be forced to enable the LAN Bypass function .
2. When the system is in the just-on state which is a brief moment when it powers up .
3. When the system is running

And the Lanner bypass possess the following features:

1. Communication through SMBUS (I2C)
2. Independent bypass status control for each pair up to a total of 4 pairs
3. Lanner Bypass Modules can bypass systems Ethernet ports on a host system during three instances: Just-on (Just-on is the brief moment when the internal power supply turns on and booting process starts), system off, or upon software request (during run-time).
4. Software programmable bypass or normal mode
5. Software programmable timer interval:
 - JUST-ON watchdog timer, used during JUST-ON, has timer setting of 5~1275 seconds of timer interval.
 - Run-Time watchdog timer, used during run-time, has setting of 1~255 seconds of timer interval.
6. Multiple Watchdog Timers:
 - Two for run-time: It is designed to give you a more variety of controls of the bypass on port basis. By using dedicated watchdogs for different pairs of bypass, you have the flexibility to manage the bypass status for them differently.
 - One for just-on: It is designed to give you the precise control of the bypass during this phase. You can use

this timer to delay enabling the bypass in just-on state.

Please refer to

Please refer to the LAN_Bypass_Watchdog folder on the Driver and Manual CD.

For sample LAN bypass code and the Bypass Manual, see the LAN_Bypass folder on the *Driver and Manual CD* or the Lanner support website at <http://www.lannerinc.com/download-center/>. And look for *Lanner Bypass Watchdog User Manual* under the *Accessories* folder.

For a description of the physical LAN ports equipped with this function, refer to *Front Panel Features* in *Chapter 1 Introduction*.

Note: For the description of the physical LAN ports equipped with LAN bypass functionality, refer to *Front Panel Features* in *Chapter 1 Introduction*.



Appendix C: Setting up Console Redirections

Console redirection lets you monitor and configure a system from a remote terminal computer by re-directing keyboard input and text output through the serial port. The following steps illustrate how to use this feature. The BIOS of the system allows the redirection of console I/O to a serial port. With this configured, you can remotely access the entire boot sequence through a console port.

1. Connect one end of the console cable to console port of the system and the other end to serial port of the Remote Client System.
2. Configure the following settings in the BIOS Setup menu:

BIOS > Advanced > Serial Port Console Redirection > Console Redirection Settings > [115200, 8 , None,1]
3. Configure Console Redirection on the client system. The following illustration is an example on Windows platform:
 - a. A. Click the start button, point to Programs > Accessories > Communications and select Hyper Terminal.
 - b. B. Enter any name for the new connection and select any icon.
 - c. Click OK.
 - d. From the "Connect to". Pull-down menu, select the appropriate Com port on the client system and click OK.
 - e. Select 115200 for the Baud Rate, None. for Flow control, 8 for the Data Bit, None for Parity Check, and 1 for the Stop Bit.



Appendix D: Programming the LCM

The LCD panel module (LCM) is designed to provide real-time operating status and configuration information for the system. For sample LCM code, see *LCM* folder in the *Driver and Manual CD*. The driver and the program library can also be found in the folder.

The system supports the following type of LCM:

- Parallel Text-based LCM: The LCM connects to the motherboard's parallel port. The LCD screen can display 2 lines, 20 characters per line.
- Parallel Graphic-based LCM: The LCM connects to the motherboard's parallel port. The LCD screen can display 128x64x1 bit matrix

Parallel Text-based LCM

Build

To build program source code on Linux platform, use the following steps as a guideline:

1. Copy the proper makefile from the Driver and Manual CD to your system: `Makefile.linux`
2. Type `make` to build source code:
`make Makefile` (Note: omit the file extensions)

After compiled, the executable programs (`plcm_test`, `plcm_cursor_char`, `Test`) and the driver (`plcm_drv.ko` or `plcm_drv.o`) will appear in the program's folder.



Note: The OS supported by Lanner LCM function include platforms based on Linux Kernel series 2.4.x and Linux Kernel series 2.6.x.

Install

Install the driver and create a node in the `/dev` directory by:

```
#insmod plcm_drv.ko
#mknod /dev/plcm_drv c 241 0
```



Note: If you cannot install the driver, check whether you have enabled the parallel port in the BIOS setting .

Execution

This section contains sample executable programs that you could test on your platform. It demonstrates some

useful functionality that the LCM provides.

To execute, type:

`#!/plcm_test`

Plcm_cursor_char. This program provides a menu to demonstrate the following functions:

Insert line (set the starting line to either line 1 or line 2)

Move Cursor right (select to move the cursor to the right)

Move Cursor Left (select to move the cursor to the left)

Add a char (select to display a character on the LCM screen)

Clear (select to clear the LCM display)

Leave (select to leave the program)

To execute, type:



Note: For descriptions of the command, refer to the *Readme* file contained within the program's folder.

Parallel Graphic-based LCM

Build

To build program source code on Linux platform, use the following steps as a guideline:

1. Copy the proper makefile from the Driver and Manual CD to your system:
`#Makefile.linux`
2. Type `make` to build source code:
`#make Makefile` (Note: omit the file extensions)

After compiled, the executable programs (`plcm_test`, `plcm_cursor_char`, `Test`) and the driver (`plcm_drv.ko`) will appear in the program's folder.



Note: The OS supported by Lanner LCM function include platforms based on Linux Kernel series 2.4.x and Linux Kernel series 2.6.x.

Install

```
#insmod plcm_drv.ko
#mknod /dev/plcm_drv c 241 0
```



Appendix E: Installing Intel QuickAssist Software for Linux

The FW-7573 platform incorporates Intel QuickAssist Technology, which includes acceleration modules that are accessed via Intel QuickAssist software. The Intel quickAssist software also enables the acceleration modules to be easily accessed by open source software such as OpenSSL. The Intel QuickAssist Technology features the acceleration to the following crypto functions:

- Symmetric Cryptographic Functions
 - Cipher Operations
 - Hash/Authenticate Operation
 - Cipher-Hash Combined Operation
 - Key Derivation Operation
- Public Key Functions
 - RSA Operation
 - Diffie-Helman Operation
 - Digital Signature Standard Operation
 - Key Derivation Operation
 - Elliptic Curve Cryptography: ECDSA* and ECDH*

We provide an abstract version of the Intel Intel® Atom™ Processor C2000 Product Family for Communications Infrastructure Software for Linux* Getting Started Guide (No. 518013). In this abstract version of Getting Started guide, it illustrates how to quickly get up and running with Fedora and Intel® Atom™ Processor C2000 Product Family for Communications Infrastructure Software for Linux Software. Refer to the attached PDF file for more information.



Appendix F: Terms and Conditions

Warranty Policy

1. All products are under warranty against defects in materials and workmanship for a period of one year from the date of purchase.
2. The buyer will bear the return freight charges for goods returned for repair within the warranty period; whereas the manufacturer will bear the after service freight charges for goods returned to the user.
3. The buyer will pay for repair (for replaced components plus service time) and transportation charges (both ways) for items after the expiration of the warranty period.
4. If the RMA Service Request Form does not meet the stated requirement as listed on "RMA Service," RMA goods will be returned at customer's expense.
5. The following conditions are excluded from this warranty:

Improper or inadequate maintenance by the customer
Unauthorized modification, misuse, or reversed engineering of the product
Operation outside of the environmental specifications for the product.

RMA Service

Requesting a RMA#

6. To obtain a RMA number, simply fill out and fax the "RMA Request Form" to your supplier.
7. The customer is required to fill out the problem code as listed. If your problem is not among the codes listed, please write the symptom description in the remarks box.
8. Ship the defective unit(s) on freight prepaid terms. Use the original packing materials when possible.
9. Mark the RMA# clearly on the box.



Note: Customer is responsible for shipping damage(s) resulting from inadequate/loose packing of the defective unit(s). All RMA# are valid for 30 days only; RMA goods received after the effective RMA# period will be rejected.



Appendix F

Terms and Conditions

RMA Service Request Form

When requesting RMA service, please fill out the following form. Without this form enclosed, your RMA cannot be processed.

RMA No:		Reasons to Return: <input type="checkbox"/> Repair(Please include failure details)	
		<input type="checkbox"/> Testing Purpose	
Company:		Contact Person:	
Phone No.		Purchased Date:	
Fax No.:		Applied Date:	
Return Shipping Address: _____			
Shipping by: <input type="checkbox"/> Air Freight <input type="checkbox"/> Sea <input type="checkbox"/> Express _____			
<input type="checkbox"/> Others: _____			
Item	Model Name	Serial Number	Configuration

Item	Problem Code	Failure Status

*Problem Code:

- | | | | |
|------------------------|------------------------------|--------------------|--------------------------|
| 01: D.O.A. | 07: BIOS Problem | 13: SCSI | 19: DIO |
| 02: Second Time R.M.A. | 08: Keyboard Controller Fail | 14: LPT Port | 20: Buzzer |
| 03: CMOS Data Lost | 09: Cache RMA Problem | 15: PS2 | 21: Shut Down |
| 04: FDC Fail | 10: Memory Socket Bad | 16: LAN | 22: Panel Fail |
| 05: HDC Fail | 11: Hang Up Software | 17: COM Port | 23: CRT Fail |
| 06: Bad Slot | 12: Out Look Damage | 18: Watchdog Timer | 24: Others (Pls specify) |

Request Party

Confirmed By Supplier

Authorized Signature / Date

Authorized Signature / Date

